



**AIR HANDLER**

**AH**

**Installation Manual**

## General Notes



### Note

- Due to ongoing research and product development, specifications, ratings, and dimensions are subject to change without notice. Refer to [www.lifebreath.com](http://www.lifebreath.com) for the latest product information.



### Attention

- All national and local code requirements must be met when installing a LIFE BREATH clean air furnace. Be sure to consult the proper authorities.
- This manual provides a guideline of good engineering practice in the design, installation and commissioning of Integrated Combo Systems. The guidelines in the manual are designed for residential forced warm air Integrated Combo Systems which utilize domestic water heaters or boilers and the Lifebreath unit. Heating and cooling loads shall be calculated in accordance with recognized Residential Heat Loss and Heat Gain Calculation methods. Duct design shall comply with recognized Residential Air System Design methods. This manual provides worksheets to be used for the purpose of sizing residential water heaters and the combo unit. Manufacturers' instructions for other components, such as the water-heater/boiler, must be followed.



### Caution

- All national and local code requirements must be met when installing this unit. Be sure to consult the proper authorities.
- This appliance complies with IAS Canada Inc. Requirement CR95-003, Additional Requirements for Fan Coil Units for use with Potable Water Heaters.
- All piping and components connected to this appliance shall be suitable for use with potable water.
- Toxic chemicals, such as used for boiler treatment, shall not be introduced into the potable water heater system.
- When using this system, and water for space heating is required to be at a higher temperature than for other uses, an anti-scald valve shall be used to ensure water for other uses is reduced in temperature to minimize a scald hazard potential.
- Combining two or more end uses such as space heating and the heating of domestic hot water in a single system has the potential to increase efficiency and reduce overall capital costs. However, the proper design, installation, and commissioning of these systems are critical if these advantages are to be realized.



### Warning

- Disconnect the power from the unit before cleaning or servicing.
- Improper installation, adjustment, alteration, service or maintenance can cause property damage, personal injury or loss of life. Installation and service must be performed by a qualified installer or service agency.
- Temperatures greater than 130°F (54°C) pose a serious risk of scalding individuals running domestic hot water for potable use.

# **Table of Contents**

1	Introduction .....	4
2	Operation Heating/Cooling .....	5
3	Combo System Basic Principles .....	6
4	Plumbing.....	7
5	Installation .....	15
6	Functions and Controls – Standard Motor .....	16
7	DIP Switch Settings – Standard Motor .....	17
8	Functions and Controls – ECM .....	18
9	DIP Switch Settings – ECM .....	19
10	Aircom Relays.....	20
11	Start-Up Procedure .....	21
12	Service/Maintenance.....	22
13	Troubleshooting.....	23
14	Specifications .....	24
15	System Commissioning.....	29
16	Wiring Diagrams (Standard motor) .....	31
17	Wiring Diagrams (ECM).....	32
18	Lifebreath Limited Warranty .....	33



# 1 INTRODUCTION

---


You will notice that the heated air in your home feels more comfortable than air heated by a conventional furnace. One reason for this is that hydronically heated air is uniform in temperate—no short blasts of hot air or hot and cold temperature spikes. In this regard, the air flowing from your hot air vents will not feel as hot to the touch as air from a conventional furnace.

With a high efficiency, adequately sized natural gas, propane or oil hot water heater/boiler, you will always have plenty of hot water for showers and baths, washing dishes and clothes, and all other normal domestic hot water needs. If there is an unusually high demand for hot water, such as filling a large hot tub, than all you need to do is allow more time for the task so the water heater/boiler can keep up to its job of providing hot water for the heating system as well as other household uses.

Once it is correctly installed, safety will never be an issue with your air handler. No flames, fumes or flue gases to be concerned about. Your domestic hot water heater/boiler now provides the heat source for your furnace.

## Overview of the Air Handler

- (1) Hydronic Coil and Pump Compartment
- (2) Aircom Electronics and Fan Compartment



## 2 OPERATION HEATING/COOLING

---

When the room thermostat calls for heat, it activates a circulation pump located inside the Air Handler. This pump delivers hot water from the water heater, through the furnace coil and back to the water tank. Simultaneously, the furnace blower switches on to high speed and will start circulating air across the coil, which picks up heat and delivers it to the rest of your home. Once the thermostat's temperature is reached the pump will shut off, and the blower will return to its pre-set speed or off.

When the thermostat calls for cooling (evaporator coil and condensing unit required), the furnace blower activates to high speed and the outdoor condenser unit is energized. After the thermostat temperature is reached, the condensing unit will shut off and the blower will return to its preset speed or off.

### **Off Season Circulation Timer**

All models are equipped with a circulation timer. It is normal operation for these models to automatically run the circulation pump for a short period of time intermittently.



### **Note**

- When the furnace blower is left running on low speed the air in the home circulates continuously. When the heat is called for the blower will automatically switch to a higher speed. After the required hot air has been delivered the blower will switch back to low speed.

### 3 COMBO SYSTEM BASIC PRINCIPLES

#### Open and Closed Systems

Open and Closed systems both deliver hot water and space heating.

Water systems that incorporate a pressure tank (i.e. well systems) are normally Open Systems and most municipal water systems are Closed Systems.


#### Closed Loop System

A system becomes closed when a Check Valve or a back-flow prevention valve is installed in the cold water piping upstream of the water heater.

A check valve will prevent water being relieved into the cold water system due to pressure created when water is heated in the water heater.

#### Drain Valve

A drain valve is required to allow the heating loop to be drained for service or repair and to remove air from the heating loop when commissioning a system. The drain valve should be near the low point of the return piping system to be near the water heater. Ball, Globe or Gate Valves are suitable for drain valves.





#### Note

- Check valves should always be installed in a vertical rise with the flow of water shown.
- Refer to local codes, local bylaws and installation manuals supplied with water heater before starting any installation work.

## 4 PLUMBING

There is an integrated check valve in the coil assembly of the CAF / AH unit.



### Note


- It should be noted that problems have been observed when using the side tappings on certain water heaters; therefore, it is strongly recommended to use the top water tappings as indicated in Figure 1 to minimize thermal siphoning and related issues.
- Take care during soldering to avoid debris or solder from lodging in the check valve.
- It is critical to follow the piping configuration shown. Maintain a minimum distance of 12" above the CAF/AH. This will minimize thermal siphoning in the combo system.




## 4 PLUMBING

### Valves

- (1) Located on the cold water side of the Heater. This valve has the ability to isolate the hot water (domestic and space heating) from the household cold water supply. Every water heater requires this valve regardless of space heating use.
- (2) Located on the hot water supply side of the heating loop, downstream of its connection to the domestic water.
- (3) Located on the return side of the heating loop upstream of its connection to the domestic cold water.




**Note:** Valves (2) and (3) isolate the heating loop for service or repair.




### Ball Valve

The Ball Valve can be used as a shut off or drain valve. When in the open position, a full bore ball valve has very little resistance to flow, and these valves tend to be both the least expensive and the least susceptible to seizing over time. Do not use reduced bore ball valves as they are very restrictive to water flow.




### Gate Valve

The Gate Valve can be used as a shut off or drain valve. When in the open position, there is very little resistance to flow. Gate valves tend to be less expensive than other types of valves but are susceptible to chatter (noise) and malfunction with age.



### Globe Valve

The Globe valve can be used as a shut off, drain or throttling valve. Even in the open position, the valve is fairly restrictive to flow. It has a much greater equivalent length (resistance.) than the other types of valves.



### Balancing (Throttling) Valve

The Balancing (Throttling) Valve is used to reduce the water flow rate and thereby increase the water temperature drop. This is done to ensure proper activation of the water heater thermostat.

A Globe Valve could also be used for Balancing (Throttling) but has more resistance than the Balancing Valve.

## 4 PLUMBING

### Call for Space Heating

There are two thermostats controlling every combo system, the water heater thermostat (controlling the hot water temperature) and the room thermostat (controlling the room air temperature). When the room thermostat calls for heat, the circulation pump is activated. Hot water is then drawn from the top of the water heater through the air handler, and then returned to the water heater.


### Hot Water Temperature Drop

The water heater thermostat will initiate the water heater as required as long as there is a 20°F (11°C) temperature drop between the hot water supplied to the air handler and the returning water.

A temperature drop less than 20°F (11°C) can cause the water heater thermostat not to initiate. This will result in a lower hot water supply temperature or poor space heating performance with fluctuating domestic water temperatures.

### Call for Domestic Hot Water and Space Heating

When both return water from the space heating loop and new cold water (replacing domestic water being used) enters the water heater, the mixed entering water is cool enough to activate the thermostat quickly. In this situation, the water heater must be capable of satisfying the combined need for domestic hot water and space heating at the same time.



### Note

- Plumbing components and system configuration may vary from diagrams portrayed.
- Chemicals (such as boiler system additives) cannot be added to a domestic hot water system.

## 4 PLUMBING

The pre-assembled, Quick Connect Kit shortens the installation time. It provides an instant, easy assembly of the major plumbing fittings required for a proper CAF/AH installation.

The Quick Connect Kit includes the WATER IN and WATER OUT assemblies. Kits are available in 1/2" and 3/4" sizes. Refer to the CAF/AH specification sheet located in the Operation and Installation Manual to obtain the correct size of water connections for the unit being installed.


Push-fit Fittings instantly make plumbing connections thereby eliminating the need for solder. Be sure to read the Push-fit Fitting Installation Instructions (included with the Quick Connect Fitting Kit) before making any connections.

### PART #99-CAF-PKit1/2

The 1/2" assembled kit.


### PART #99-CAF-PKit3/4

The 3/4" assembled kit.



**WATER IN  
assembly**

**WATER OUT  
assembly**



## 4 PLUMBING

### Air System

A circulation fan draws cool house air at approx. 70°F (21°C) from the return ductwork, forces it through the water coil where it is heated, and then distributes it to the various rooms of the house through the supply ductwork.

### Water System Pressures

Within the water system of an Integrated Combo system, there are three terms that the designer/installer must understand. These are:

- Head pressure
- Water flow rate
- Pressure drop

### Head Pressure

Head pressure is the pressure created by the circulation pump to push water through the piping system. It is this pressure which is used to overcome the resistance to water flow (friction) caused by the water pipe and fittings. It is similar in concept to the external static pressure in an air duct system. Head pressure is measured in feet of water (millimeters of water).

### Water Flow Rate

Water flow rate is the amount of water flowing in the system. It is directly related to the head pressure and the resistance to flow. Flow rate is measured in gallons per minute (liters per minute).

### Pressure Drop (PD)

Pressure drop (PD) is the reduction in total pressure caused by components added to a piping system such as coils, valves, and fittings. The measurement of pressure drop is the difference in pressure on the inlet side of the component and the outlet side. Pressure drop is measured in feet of water (millimeters of water).


When connecting the water lines for heating loop (air handler) to the domestic water system, the pipes should be connected with a "tee" to the side of a vertical domestic water pipe or the bottom of a horizontal domestic water pipe. This is to help prevent air from entering the heating loop. The connections should be as near as practical to the water heater.

### Circulation Pump

The circulation pump is factory installed within the air handler. The water flow rate will vary depending on the pumps performance and the head pressure (resistance) of the complete heating loop system.

The piping and fittings used to connect the water heater and air handler must be sized to handle the volume of hot water required by the air handler within the pressure limitations of the circulation pump. All piping, fittings solders, and fluxes must be acceptable for use with domestic hot water.

Water Pump Performance Specifications



### Note

- The vertical height of the heating loop does not impact on the head pressure as the pressure required to push the water up the vertical height is offset by the weight of the water in the vertical drop on the other side of the heating loop.

## 4 PLUMBING

---

### Air Handler Output Capacity

There are four factors that will significantly affect the heating output of the air handler.

They are:

- Hot water supply temperature (EWT)
- Hot water flow rate (GPM)
- Air Handler return air temperature
- Air Handler air flow rate (CFM)Head Pressure

### Hot Water Supply Temperature

The hot water supply temperature is controlled by the water heater thermostat. This is set by the installing contractor to provide the required temperature at the hot water outlet of the water heater.

The hot water supply temperature is typically 140°F (60°C). If this temperature must be increased to achieve higher out-puts from the furnace an anti-scald valve must be used to prevent domestic hot water temperatures above 140°F (60°C). The manufacturer of the Hot water Tank should be consulted for temperatures higher than 140°F (60°C).

It is important that a warning label be placed near the water heater thermostat telling the homeowner not to change the thermostat setting. The label is included with the furnace.

### Hot Water Flow Rate

The hot water entering the water coil is the source of heat to the air handler. The effect of changing the amount of water entering the coil is the same as changing the water temperature. As water flow is reduced, the output of the air handler and the air temperature rise will both be lowered.

### Air Handler Return Air Temperature

The return air temperature entering the air handler is approx. 60°F (33°C) below the hot water inlet temperature. If the return air temperature entering the air handler is reduced, more heat transfer will occur and the output of the air handler will increase.

### Air Handler Air Flow Rate

The air entering the air handler can only be warmed by the temperature difference between the hot water and the cool air. As the volume (CFM (L/s)) of air is reduced, the amount of heat which can be transferred is also reduced.

### Air Handler Temperature Rise

In a fuel fired furnace, the combustion gases can be 1000°F (538°C) above the return air temperature. These units typically have a temperature rise from 50°F (10°C) to 90°F (32°C) and therefore delivers air at the diffuser at 120°F (49°C) to 160°F (71°C).

With an Integrated Combo System, the hot water temperature is approx. 130°F (54°C) which is 60°F (15.5°C) above the return air temperature. These units typically have a temperature rise of 35°F (2°C) to 40°F (4°C) and therefore would deliver air at the diffuser at approximately 105°F (40.5°C) to 110°F (43°C).



### Note

- Although the water in the combo system is pressurized by the domestic water system the pump is required to create water flow in the heating loop. The domestic water system applies the same pressure to the supply and return sides of heating loop.

## 4 PLUMBING

---

### Room Thermostat

The room thermostat controls both the water circulation pump and the air circulation fan. It should be on a centrally located, inside wall away from any source of heat such as diffusers, appliances and direct sunlight.

### Energy Saving Room Thermostat

A "set back" thermostat or "smart stat" can be used with a combo system, but care must be taken in the timing of the temperature changes. The timing of morning warm up should be early enough that the desired air temperature has been reached before the people begin to use domestic hot water. The highest demand for space heating is during the morning warm up and the highest demand for domestic hot water is during morning showers. Even if the water heater is properly sized, it may not be able to meet this combined load. Therefore, large setbacks should be avoided.

### Design vs. Field Conditions

The factors discussed between design parameters and actual field conditions can impact greatly on output capacity. Therefore, it is important to do a thorough and complete commissioning of the integrated combo system to ensure the design parameters are met.

### Piping

The hot water piping between the hot water tank and the Air Handler should be new copper type, and should not be treated with chemicals, sealant or anything else, that will interfere with the purity of the potable water. Only non-lead, low temperature solder is permitted for sealing copper joints.

Where possible the length of pipe should not exceed 200' total equivalent length. Any piping running through unconditioned space must be insulated to prevent heat loss, and possible freezing of the line.

Look inside the furnace and locate the pump. Attach the "Hot Water In" (Supply) to the pipe running to the pump. Attach the "Hot Water Out" (Return) to the pipe running to the coil. Do not reverse these lines, as this will cause the unit to malfunction.

For piping conventional water heaters, connections to and from the Air Handler to the water tank should be made at the point where the pipes leave the tank vertically. A "T" fitting used in each vertical line, with the Air Handler piping connected to the horizontal side of this fitting, will work best in avoiding air locks in the circulation pump of the furnace.



### Note

- Remove shipping block from underneath pump and discard.

## 5 INSTALLATION

---

### Locating the Unit

The Air Handler is designed to be installed vertically, in a conditioned space, where the surrounding temperature does not fall below 50°F (10°C). Attic installations are not recommended. Typically, the unit is installed in a mechanical area of the basement, or other partitioned mechanical room, elsewhere in the home. A location close to an outside wall is recommended, as the ventilation supply and exhaust portion will need to be duct-ed to the outside air. Enough clearance around the unit is required for service of the filter, heat recovery core and components. As a rule, this unit should be installed adjacent to the hot water heater. If this is not possible, or if the piping layout is complex, the total head pressure on the pump should be calculated.

### Ducting

The duct sizing for the furnace section can be determined using HRAI Residential Air System Design Manual, SMACNA, or any other industry-recognized manuals. Note: Any ductwork running through unconditioned space must be sealed properly and insulated to prevent heat loss. All local codes must be followed in determining the amount of insulation needed.

### Duct Connections

Penetrations from sheet metal screws used to fasten the ductwork to the cabinet of the unit should only be placed into the duct flange provided. This is to avoid contact and damage of the heating/air conditioning coils and internal wiring.



### Note


- All national and local codes relating to this type of equipment must be followed.
- "Combo units" normally deliver air at approx. 110°F (43°C), and therefore may require larger than normal ductwork. When installing the Air Handler as a replacement unit on a retrofit application, always calculate the size of duct that is there.

## 6 FUNCTIONS AND CONTROLS – STANDARD MOTOR

### Basic Functions

- C – Common
- R – 24 volt supply
- W – Medium or High Fan Relay with Circulation Pump (the speed depends on DIP switch #6 setting)
- Y&G – Medium or High Fan Relay (the speed depends on DIP switch #7 setting)
- G – Low Speed Fan Relay
- O – High Speed Fan Relay with Circulation Pump

### Aircon Circuit Board



### Thermostat Heat Anticipator Settings

- Mechanical Thermostats - start at 0.5 amp and may need to be increased depending upon the residual heat left in the hydronic coil and duct work.
- Electronic Thermostats – to be set on electric style heat

### Off Season Circulation Timer

Water is periodically circulated throughout the space heating loop during the summer and other periods of infrequent use. The concern is that water which remains stationary in the heating loop during the summer may be less than desirable as domestic hot water when it is returned to the water heater at system startup in the fall.

## Warning

- Do not energize the Air Handler until the plumbing is connected and commissioned. Failure to do so will damage the pump.

## 7 DIP SWITCH SETTINGS – STANDARD MOTOR

### Main board DIP Switch

- DIP Switch #2 to ON will disable the Off Season Circulation Timer
- DIP Switch #6 to ON will select Medium Speed for heating (Factory Setting is OFF for High Speed)
- DIP Switch #7 ON will select Medium Speed for cooling (Factory Setting is OFF for High Speed)

→ ON



### Warning


- Do not adjust any other DIP switches than indicated above.

# 8 FUNCTIONS AND CONTROLS – ECM

## Basic Functions

- Thermostat fan switch will control low speed fan operation
- Call for heating – high speed
- Call for cooling – high speed

## Aircom Circuit Board



## Thermostat Heat Anticipator Settings

- Mechanical Thermostats - start at 0.5 amp and may need to be increased depending upon the residual heat left in the hydronic coil and duct work.
- Electronic
- Thermostats – to be set on electric style heat


**Warning**

- Do not energize the AH until the plumbing is connected and commissioned. Failure to do so will damage the pump.


## 9 DIP SWITCH SETTINGS – ECM

### Main Circuit Board DIP Switch

- DIP Switch #2 to ON will disable the Off Season Circulation Timer
- DIP Switch #6 Factory Setting is ON
- DIP Switch #7 Factory Setting is ON



### ECM Circuit Board DIP Switch



Switch Settings		Fan Speeds
Cool Switches		
1	2	Cool
OFF	OFF	High
ON	OFF	Med. High
OFF	ON	Med. Low
ON	ON	Low

Switch Settings		Fan Speeds
Heat Switches		
3	4	Heat
OFF	OFF	High
ON	OFF	Med. High
OFF	ON	Med. Low
ON	ON	Low

Switch Settings		Fan Speeds	
Adjust Switches		Heat	Cool
5	6		
OFF	OFF	Normal	Normal
ON	OFF	Increase 15%	Increase 15%
OFF	ON	Decrease 15%	Decrease 15%
ON	ON	Normal	Normal

**Note:** Delay Switches have no function currently.

## Warning


- Do not adjust any other DIP switches than indicated above.
- DIP switches #6 and #7 on Main Circuit Board must be ON for the ECM motor to function (factory setting)
- Refer to individual specification pages for Airflow Performance specifications. Above settings correspond to DIP switch settings on the ECM circuit board only. Do not adjust DIP switches on Main Circuit Board.

## 10 AIRCOM RELAYS

The Aircom circuit board has three available "dry contact" relays. Contact 3 is not available.


### Contact 1

- This relay is a dry contact (no power supplied from board). The relay switches upon a call for heat.
- This relay can be used to switch the heat demand signal for boiler operation.
- Power (if required) must be supplied to common from an external source.
- Max. Voltage - 120 volts
- Max. Amperage - 10 amps
- Maximum 115V 10 amp resistive load.



### Contact 2 and 4

- These relays are dry contacts (no power supplied from board). The relays switch whenever the CAF blower motor is operating.
- These relays can be used to interlock Humidifiers, Air Cleaning Equipment, etc.
- Power (if required) must be supplied to common from an external source.
- Max. Voltage - 120 volts
- Max. Amperage - 10 amps



## 11 START-UP PROCEDURE

---

For any appliance to work properly it must be set up and tested by a knowledgeable technician.

### The following conditions must be met prior to start-up

1. Ensure that connecting water lines are purged and free of debris.
2. Caution: solder or other debris may cause the furnace pump or check valve to malfunction.
3. Blower wheel rotates freely inside its housing.
4. Wiring connections are tight.
5. All duct and pipe connections are sealed.
6. Check that styrene block is removed from under pump.
7. Front access door is on tight.
8. Fan speed selection:
  - a) Heating/Cooling - factory setting is at high speed and can be changed in the electrical box to medium-high or medium if required.

### Once the necessary connections have been made, follow the procedure:

Step 1. Close shut-off valves separating the Air Handler from the water heater.

Step 2. Set up water heater according to manufacturer's instructions.

Step 3. Purge air from unit. To do so, open the supply shut-off valve to the furnace. Attach a garden hose to drain valve and drain water until you get a continuous flow. Close the drain valve and purge the pump. To purge the air from the pump, turn the large screw on the face of the pump counterclockwise until water leaks out, then tighten. Open the supply shut-off valve.

Step 4. Turn on power supply to Air Handler. **Caution:** *Blower may start to operate at low speed.*

Step 5. Switch the room thermostat to heat. The thermostat should be set higher than the current room temperature in order to energize the pump and commence the heating cycle. (If the pump does not start, or the Air Handler is not producing heat, refer to the Troubleshooting Section in this manual.)

Step 6. Set room thermostat at desired temperature setting.


## 12 SERVICE/MAINTENANCE

A dedicated maintenance program will prolong the life of the equipment and maintain its optimum performance.

We recommend at least two full inspections and cleanings per year under normal operating conditions, and more if circumstances warrant it (i.e. situations of heavy smoke may require servicing every one to two months).

### Figure Callouts:

- (1) Hot Water Supply/Return
- (2) Hot Water Circulation Pump
- (3) Filter
- (4) PSC type hi-efficiency motor
- (5) Ultra-efficient heating coil



### Service Should Include:

- Inspect filter and replace as necessary
- Inspect operation of blowers and electrical panel
- Confirm operation

## 13 TROUBLESHOOTING

Refer to the following table for troubleshooting your Air Handler.

**Table 5.1 – Troubleshooting Procedures (cont.)**

<b>SYMPTOM</b>	<b>CAUSE</b>	<b>SOLUTION</b>
Lack of Heat	<ul style="list-style-type: none"> <li>Several factors may contribute to this problem, follow the steps in the Solution column.</li> </ul>	<ol style="list-style-type: none"> <li>Check that the room thermostat is set to the desired temperature.</li> <li>Confirm the units have power and the shut-off valves are open.</li> <li>Ensure there is power to the unit and that the pump is working. If the pump is not working properly it may be stuck.               <ul style="list-style-type: none"> <li>Disconnect power and remove screw in center face of the pump.</li> <li>Using a screwdriver, turn the pump shaft several times to free it from sticking.</li> <li>Replace center-screw and re-connect power.</li> <li>If pump still fails to start, it may require replacement.</li> </ul> </li> <li>Confirm that the hot water heater is working, and that hot water is entering the Air Handler.</li> <li>Make sure your water heater is sized large enough for heat load of house and for domestic hot water use.</li> <li>Air may still be in the water lines. If so, re-purge the system according to the startup procedure.</li> <li>Confirm that the inlet and outlet pipe connections are not reversed.</li> <li>Ensure that there are no other restrictions in the water lines, such as faulty valves, or debris.</li> </ol>
Pump is noisy	<ul style="list-style-type: none"> <li>Pumps can become noisy when air remaining in the lines interfere with their operation.</li> </ul>	<ul style="list-style-type: none"> <li>Re-purge the system as indicated in the Start-Up Procedure.</li> </ul>
During cooling cycle, hot water circulates through the coil	<ul style="list-style-type: none"> <li>If the check valve inside the cabinet is stuck in the open position, hot water may infiltrate the heating coil. This occurs when the hot pipes are not capped-off during installation or service and foreign debris enters the piping. This debris can settle under the check valve seat and permit hot water to flow into the coil.</li> </ul>	<ul style="list-style-type: none"> <li>Repeatedly flush the heating loop until it is clean.</li> </ul>

# 14 SPECIFICATIONS


## S4A-24 Coil Output Chart (1000's of BTUH)

CFM @ 0.5" w.g.	<b>890</b>	40.7	47.7	54.8	61.9	69.0	76.2
	<b>790</b>	38.0	44.5	51.0	57.6	64.3	70.9
	<b>740</b>	36.5	42.7	49.0	55.3	61.7	68.0
	<b>660</b>	33.8	39.6	45.5	51.3	57.2	63.0
CFM @ 0.25" w.g.	<b>1030</b>	44.0	51.7	59.3	67.0	74.8	82.5
	<b>900</b>	41.0	48.0	55.1	62.3	69.4	76.6
	<b>825</b>	38.9	46.7	52.4	59.2	66.0	72.8
	<b>740</b>	36.5	42.7	49.0	55.3	61.7	68.0
Water Temp. (°F)		<b>130</b>	<b>140</b>	<b>150</b>	<b>160</b>	<b>170</b>	<b>180</b>
<b>3 GPM</b>							


CFM @ 0.5" w.g.	<b>890</b>	43.8	51.3	58.9	66.5	74.1	81.7
	<b>790</b>	40.5	47.4	54.4	61.3	68.3	75.4
	<b>740</b>	38.7	45.3	51.9	58.6	65.3	72.0
	<b>660</b>	35.6	41.7	47.8	53.9	60.0	66.2
CFM @ 0.25" w.g.	<b>1030</b>	48.0	56.2	64.5	72.8	81.2	89.6
	<b>900</b>	44.1	51.7	59.3	66.9	74.6	82.3
	<b>825</b>	41.7	48.8	56.0	63.2	70.4	77.6
	<b>740</b>	38.7	45.5	51.9	58.6	65.3	72.0
Water Temp. (°F)		<b>130</b>	<b>140</b>	<b>150</b>	<b>160</b>	<b>170</b>	<b>180</b>
<b>4 GPM</b>							

CFM @ 0.5" w.g.	<b>890</b>	45.7	53.6	61.4	69.3	77.2	85.1
	<b>790</b>	42.0	49.2	64.4	63.6	70.8	78.0
	<b>740</b>	40.0	46.8	53.7	60.5	67.4	74.3
	<b>660</b>	36.7	42.9	49.2	55.4	61.7	68.0
CFM @ 0.25" w.g.	<b>1030</b>	50.5	59.1	67.8	76.5	85.3	94.1
	<b>900</b>	46.1	54.0	61.9	69.8	77.8	85.8
	<b>825</b>	43.5	50.9	58.3	65.8	73.3	80.8
	<b>740</b>	40.0	46.9	53.7	60.5	67.4	74.3
Water Temp. (°F)		<b>130</b>	<b>140</b>	<b>150</b>	<b>160</b>	<b>170</b>	<b>180</b>
<b>5 GPM</b>							


<b>AH-U-S4A-24-P16/E16</b>	
Voltage	120 Vac 60 HZ
HP	1/3
Amps (total)	8
Water Connections	1/2 in. (13 mm) Copper Soldered Connection
Airflow (high) 0.25 in w.g. 0.5 in. w.g.	1030 CFM 890 CFM
Net Weight	111 lbs. (50.3 kg)
Shipping Weight	130 lbs. (59 kg)



**Note:** Return plenum opening available off either side of cabinet.



Service Clearance: 12 in. (305 mm)



Service Clearance: 36 in. (914 mm)

# 14 SPECIFICATIONS


## L4A-36 Coil Output Chart (1000's of BTUH)

CFM @ 0.5" w.g.	<b>1180</b>	51.4	60.2	69.0	77.9	86.8	95.8
	<b>1120</b>	50.0	58.7	67.2	75.9	84.5	93.2
	<b>890</b>	43.9	51.4	60.0	66.5	74.1	81.7
	<b>675</b>	36.6	42.8	49.0	55.3	61.5	67.8
CFM @ 0.25" w.g.	<b>1350</b>	54.7	64.2	73.6	83.1	92.6	102.1
	<b>1275</b>	53.3	62.5	71.7	80.9	90.2	99.5
	<b>940</b>	45.4	53.2	60.9	68.8	76.6	84.5
	<b>730</b>	38.6	45.2	51.8	58.4	65.0	71.7
Water Temp. (°F)	<b>130</b>	<b>140</b>	<b>150</b>	<b>160</b>	<b>170</b>	<b>180</b>	
<b>3 GPM</b>							


CFM @ 0.5" w.g.	<b>1180</b>	56.3	65.9	75.6	85.3	95.0	104.8
	<b>1120</b>	54.5	63.9	73.2	82.6	92.0	101.5
	<b>890</b>	46.9	54.9	62.9	70.9	79.0	87.1
	<b>675</b>	38.2	44.7	51.2	57.7	64.2	70.7
CFM @ 0.25" w.g.	<b>1350</b>	60.8	71.2	81.7	92.2	102.7	113.3
	<b>1275</b>	58.9	69.0	79.1	89.3	99.5	109.7
	<b>940</b>	48.7	57.0	65.3	73.7	82.1	90.4
	<b>730</b>	40.6	47.5	54.4	61.3	68.3	75.2
Water Temp. (°F)	<b>130</b>	<b>140</b>	<b>150</b>	<b>160</b>	<b>170</b>	<b>180</b>	
<b>4 GPM</b>							

CFM @ 0.5" w.g.	<b>1180</b>	59.4	69.5	79.7	89.9	100.1	110.3
	<b>1120</b>	57.4	67.1	76.9	86.8	96.6	106.5
	<b>890</b>	48.7	56.9	65.3	73.5	81.8	90.2
	<b>675</b>	37.3	43.7	50.0	56.4	62.8	69.2
CFM @ 0.25" w.g.	<b>1350</b>	64.7	75.8	86.8	98.0	109.2	120.4
	<b>1275</b>	62.4	73.1	83.8	94.5	105.3	116.5
	<b>940</b>	50.7	59.3	67.9	76.6	85.3	94.0
	<b>730</b>	41.8	48.8	55.9	63.0	70.1	77.2
Water Temp. (°F)	<b>130</b>	<b>140</b>	<b>150</b>	<b>160</b>	<b>170</b>	<b>180</b>	
<b>5 GPM</b>							


<b>AH-U-L4A-36-P16/E16</b>	
Voltage	120 Vac 60 HZ
HP	1/2
Amps (total)	10.6
Water Connections	3/4 in. (19 mm) Copper Soldered Connection
Airflow (high) 0.25 in w.g.	1350 CFM
0.5 in. w.g.	1180 CFM
Net Weight	121 lbs. (54.9 kg)
Shipping Weight	140 lbs. (63.6 kg)



**Note:** Return plenum opening available off either side of cabinet.



Service Clearance: 12 in. (305 mm)



Service Clearance: 36 in. (914 mm)

# 14 SPECIFICATIONS


## S2A-30 Coil Output Chart (1000's of BTUH)

CFM @ 0.5" w.g	<b>1075</b>	27.5	32.3	37.0	41.6	46.6	51.1
	<b>1040</b>	27.3	31.9	36.4	41.0	45.8	50.4
	<b>975</b>	26.3	30.8	35.3	39.8	44.1	48.8
	<b>880</b>	25.0	29.2	33.5	38.0	42.2	46.5
CFM @ 0.25" w.g	<b>1280</b>	29.8	35.0	40.0	45.1	50.3	55.8
	<b>1200</b>	28.9	33.9	38.8	43.8	48.9	53.9
	<b>1000</b>	26.5	31.1	35.6	40.2	44.8	49.4
	<b>1020</b>	26.8	31.4	36.2	40.7	45.3	50.0
Water Temp. (°F)		<b>130</b>	<b>140</b>	<b>150</b>	<b>160</b>	<b>170</b>	<b>180</b>
<b>3 GPM</b>							


CFM @ 0.5" w.g	<b>1075</b>	29.0	34.1	39.1	44.2	49.3	54.2
	<b>1040</b>	28.7	33.6	38.4	43.4	48.5	53.3
	<b>975</b>	27.7	32.8	37.3	42.0	46.9	51.6
	<b>880</b>	26.4	31.0	35.4	39.9	44.5	49.1
CFM @ 0.25" w.g	<b>1280</b>	31.8	37.3	42.8	48.3	53.9	59.4
	<b>1200</b>	30.9	36.1	41.4	46.8	52.1	57.4
	<b>1000</b>	28.2	33.0	37.8	42.6	47.4	52.3
	<b>1020</b>	28.3	33.1	37.9	42.9	47.8	52.8
Water Temp. (°F)		<b>130</b>	<b>140</b>	<b>150</b>	<b>160</b>	<b>170</b>	<b>180</b>
<b>4 GPM</b>							

CFM @ 0.5" w.g	<b>1075</b>	30.5	35.4	40.8	45.9	51.1	56.5
	<b>1040</b>	29.8	35.0	40.1	45.1	50.2	55.2
	<b>975</b>	28.8	33.8	38.4	43.5	48.3	53.3
	<b>880</b>	27.4	32.0	36.6	41.3	45.9	50.5
CFM @ 0.25" w.g	<b>1280</b>	33.4	38.9	44.8	50.6	56.2	62.2
	<b>1200</b>	32.2	37.7	43.2	48.7	54.2	59.8
	<b>1000</b>	29.2	34.2	39.2	44.2	49.2	54.2
	<b>1020</b>	29.4	34.6	39.6	44.7	49.8	54.9
Water Temp. (°F)		<b>130</b>	<b>140</b>	<b>150</b>	<b>160</b>	<b>170</b>	<b>180</b>
<b>5 GPM</b>							


<b>AH-U-S2A-30-P16/E16</b>	
Voltage	120 Vac 60 HZ
HP	1/3
Amps (total)	8
Water Connections	1/2 in. (13 mm) Copper Soldered Connection
Airflow (high)	0.25 in w.g. 1280 CFM 0.5 in. w.g. 1075 CFM
Net Weight	111 lbs. (50.3 kg)
Shipping Weight	130 lbs. (59 kg)



**Note:** Return plenum opening available off either side of cabinet.



Service Clearance: 12 in. (305 mm)



Service Clearance: 36 in. (914 mm)

# 14 SPECIFICATIONS


## L2A-36 Coil Output Chart (1000's of BTUH)

CFM @ 0.5" w.g.	<b>1220</b>	32.9	38.5	44.2	49.8	55.4	61.1
	<b>1175</b>	32.8	37.8	43.3	48.9	54.4	60.0
	<b>1022</b>	30.2	35.3	40.4	45.6	50.8	55.9
	<b>705</b>	24.7	28.9	33.1	37.3	41.5	45.7
CFM @ 0.25" w.g.	<b>1402</b>	35.1	41.0	47.0	53.1	59.1	65.1
	<b>1357</b>	34.6	40.4	46.4	52.3	58.2	64.2
	<b>1090</b>	31.2	36.5	41.8	47.1	52.4	57.8
	<b>731</b>	25.5	29.5	33.8	38.1	42.4	46.7
Water Temp. (°F)		<b>130</b>	<b>140</b>	<b>150</b>	<b>160</b>	<b>170</b>	<b>180</b>
<b>3 GPM</b>							


CFM @ 0.5" w.g.	<b>1220</b>	35.2	41.2	47.2	53.2	59.2	65.3
	<b>1175</b>	34.5	40.4	46.2	52.1	58.0	63.9
	<b>1022</b>	32.0	37.5	42.9	48.4	53.8	59.3
	<b>705</b>	25.9	30.2	34.6	39.0	43.4	47.8
CFM @ 0.25" w.g.	<b>1402</b>	37.7	44.1	50.6	57.0	63.5	70.0
	<b>1357</b>	37.1	43.4	49.8	56.1	62.5	68.9
	<b>1090</b>	33.2	38.8	44.4	50.1	55.8	61.4
	<b>731</b>	26.4	30.9	35.4	39.9	44.4	48.9
Water Temp. (°F)		<b>130</b>	<b>140</b>	<b>150</b>	<b>160</b>	<b>170</b>	<b>180</b>
<b>4 GPM</b>							

CFM @ 0.5" w.g.	<b>1220</b>	36.7	43.0	49.2	55.4	61.7	68.0
	<b>1175</b>	36.0	42.0	48.1	54.3	60.4	66.5
	<b>1022</b>	33.3	38.9	44.5	50.2	55.8	61.5
	<b>705</b>	26.6	31.1	35.6	40.1	44.6	49.1
CFM @ 0.25" w.g.	<b>1402</b>	39.5	46.2	52.9	59.7	66.4	73.2
	<b>1357</b>	38.8	45.4	52.0	58.7	65.3	71.9
	<b>1090</b>	34.5	40.3	46.2	52.0	57.9	63.8
	<b>731</b>	27.2	31.8	36.4	41.0	45.6	50.2
Water Temp. (°F)		<b>130</b>	<b>140</b>	<b>150</b>	<b>160</b>	<b>170</b>	<b>180</b>
<b>5 GPM</b>							


<b>AH-U-L2A-36-P16/E16</b>	
Voltage	120 Vac 60 HZ
HP	1/2
Amps (total)	10.6
Water Connections	1/2 in. (13 mm) Copper Soldered Connection
Airflow (high) 0.25 in w.g.	1402 CFM
0.5 in. w.g.	1220 CFM
Net Weight	121 lbs. (54.9 kg)
Shipping Weight	140 lbs. (59 kg)



**Note:** Return plenum opening available off either side of cabinet.



Service Clearance: 12 in. (305 mm)



Service Clearance: 36 in. (914 mm)

# 14 SPECIFICATIONS


## L2B-48 Coil Output Chart (1000's of BTUH)

CFM @ 0.5" w.g	<b>1639</b>	37.5	43.9	50.3	56.8	63.3	69.7
	<b>1618</b>	37.3	43.7	50.0	56.5	62.9	69.3
	<b>1575</b>	36.9	43.2	49.5	55.8	62.2	68.6
CFM @ 0.25" w.g	<b>1967</b>	40.4	47.3	54.2	61.1	68.1	75.1
	<b>1868</b>	39.6	46.3	53.1	59.9	66.7	73.6
	<b>1728</b>	38.3	44.9	51.4	58.1	64.7	71.3
Water Temp. (°F)	<b>130</b>	<b>140</b>	<b>150</b>	<b>160</b>	<b>170</b>	<b>180</b>	
<b>3 GPM</b>							


CFM @ 0.5" w.g	<b>1639</b>	40.7	47.6	54.5	61.5	68.5	75.5
	<b>1618</b>	40.4	47.2	54.2	61.1	68.0	75.0
	<b>1575</b>	39.9	46.7	53.5	60.3	67.2	74.0
CFM @ 0.25" w.g	<b>1967</b>	44.1	51.6	59.2	66.7	74.3	81.9
	<b>1868</b>	43.1	50.5	55.8	65.2	72.7	80.1
	<b>1728</b>	41.6	48.7	55.9	63.0	70.2	77.3
Water Temp. (°F)	<b>130</b>	<b>140</b>	<b>150</b>	<b>160</b>	<b>170</b>	<b>180</b>	
<b>4 GPM</b>							

CFM @ 0.5" w.g	<b>1639</b>	42.8	50.0	57.3	64.6	71.9	79.3
	<b>1618</b>	42.5	49.7	56.9	64.2	71.5	78.7
	<b>1575</b>	41.9	49.0	56.1	63.3	70.5	77.7
CFM @ 0.25" w.g	<b>1967</b>	46.7	54.6	62.5	70.5	78.5	86.6
	<b>1868</b>	45.5	53.3	61.1	68.8	76.7	84.5
	<b>1728</b>	43.9	51.3	58.8	66.3	73.8	81.4
Water Temp. (°F)	<b>130</b>	<b>140</b>	<b>150</b>	<b>160</b>	<b>170</b>	<b>180</b>	
<b>5 GPM</b>							


<b>AH-U-L2B-48-P16/E16</b>	
Voltage	120 Vac 60 HZ
HP	3/4
Amps (total)	12.2
Water Connections	1/2 in. (13 mm) Copper Soldered Connection
Airflow (high)	
0.25 in w.g.	1967 CFM
0.5 in. w.g	1639 CFM
Net Weight	135 lbs. (61.2 kg)
Shipping Weight	155 lbs. (70.3 kg)



**Note:** Return plenum opening available off either side of cabinet.



Service Clearance: 12 in. (305 mm)



Service Clearance: 36 in. (914 mm)

## 15 SYSTEM COMMISSIONING

This section of the manual is designed to be used with the "Commissioning of Integrated Combo System" worksheet. The worksheet is designed to guide you through the start-up process in a logical, step by step method which should minimize the work and time involved in having the system meet the designed parameters.

The following conditions are assumed:

- The air filter is in place.
- All supply diffusers and return grilles are fully open and unrestricted.
- Hot water is available to the furnace.
- The drain valve for the heating loop is closed.
- The shut-off valves for the heating loop are fully open.
- The throttling valve for the heating loop (if applicable), is fully opened.
- Electrical power is available to the furnace.
- The return air temperature from house is approximately 70°F (21°C).

<b>Commissioning of Integrated Combo System</b>	
<b>Designer/Signature:</b> _____	
<b>Phone:</b> _____ <b>E-mail:</b> _____ <b>Date:</b> _____	
<p style="text-align: center;"><b>Submitted For: (Owner)</b></p> <p><b>Name:</b> _____</p> <p><b>Address:</b> _____</p> <p><b>City:</b> _____      <b>Province:</b> _____</p> <p><b>Postal Code:</b> _____</p> <p><b>Phone:</b> _____      <b>E-mail:</b> _____</p>	<p style="text-align: center;"><b>By: (Contractor)</b></p> <p><b>Name:</b> _____</p> <p><b>Address:</b> _____</p> <p><b>City:</b> _____      <b>Province:</b> _____</p> <p><b>Postal Code:</b> _____</p> <p><b>Phone:</b> _____      <b>E-mail:</b> _____</p>

<b>Installed Equipment</b>	
<ul style="list-style-type: none"> <li><input type="checkbox"/> Water Heater make &amp; model as designed</li> <li><input type="checkbox"/> Air Handler make &amp; model as designed</li> <li><input type="checkbox"/> Cooling Unit make &amp; model as designed</li> <li><input type="checkbox"/> Filter type and size as designed</li> <li><input type="checkbox"/> 2 shut off valves for heating loop</li> <li><input type="checkbox"/> Check Valve</li> <li><input type="checkbox"/> Drain Valve</li> </ul>	<ul style="list-style-type: none"> <li><input type="checkbox"/> Throttling Valve</li> <li><input type="checkbox"/> Anti-scalding Valve</li> <li><input type="checkbox"/> Back Flow Prevention valve</li> <li><input type="checkbox"/> Expansion Tank</li> <li><input type="checkbox"/> Off Season Circulation Controls</li> <li><input type="checkbox"/> Other</li> </ul>

# 15 SYSTEM COMMISSIONING

System Start Up	
<input type="checkbox"/> Fill Water-Heater with water <input type="checkbox"/> Set Water-Heater at designed temperature <input type="checkbox"/> Fill Heating Loop with water <input type="checkbox"/> Purge Circulation Pump	<input type="checkbox"/> Start Air Handler <input type="checkbox"/> Check Circulation Pump Operation <input type="checkbox"/> Check Circulation Fan Operation <input type="checkbox"/> Label Water-Heater

System Commissioning			
<input type="checkbox"/> Total Heat Loss <input type="checkbox"/> Air Handler Output <input type="checkbox"/> Eff. Water-Heater Output <input type="checkbox"/> Air Handler ESP <input type="checkbox"/> Air Flow Rate <input type="checkbox"/> Fan Speed	_____ Btu/h _____ Btu/h _____ Btu/h _____ in. W.C. _____ CFM _____	<input type="checkbox"/> Supply Water Temperature <input type="checkbox"/> Return Water Temperature <input type="checkbox"/> Supply Air Temperature <input type="checkbox"/> Return Air Temperature	_____ °F _____ °F _____ °F _____ °F
a. Supply Water Temperature <i>(measured)</i> b. Air Handler Output (at <b>a</b> ) c. Air Handler Operating CFM <i>(measured)</i> d. Return Air Temperature <i>(measured)</i> e. Required Air Temperature Difference ( <b>b</b> / (1.08 x <b>c</b> ))	_____ °F _____ Btu/h _____ CFM _____ °F _____ °F	f. Required Supply Air Temperature ( <b>d</b> + <b>e</b> ) g. Returned Water Temperature <i>(measured)</i> h. Water Temperature Difference ( <b>a</b> – <b>g</b> ) i. Actual Supply Air Temperature <i>(measured)</i> j. Anti-Scald valve Outlet Temperature <i>(measured)</i>	_____ °F _____ °F _____ °F (min. 20°F) _____ °F _____ °F

# 16 WIRING DIAGRAMS (STANDARD MOTOR)

## CAUTION


Electrical control panel service by electrician only. Disconnect electrical supply prior to servicing. Improper wiring may result in damage to this unit. Use copper supply wires.

## ATTENTION

Entretien du panneau de contrôle électrique par un électricien seulement. Coupez l'alimentation électrique avant de procéder à l'entretien. Un câblage inadéquat pourrait endommager cet appareil. Utilisez des câbles de cuivre

### Standard Motor CAF/Air Handler Wiring Diagram

### Schéma de câblage d'un moteur de FAP/Appareil de traitement de l'air standard



60-CAF-AH-01

# 17 WIRING DIAGRAMS (ECM)

## CAUTION


Electrical control panel service by electrician only. Disconnect electrical supply prior to servicing. Improper wiring may result in damage to this unit. Use copper supply wires.

## ATTENTION

Entretien du panneau de contrôle électrique par un électricien seulement. Coupez l'alimentation électrique avant de procéder à l'entretien. Un câblage inadéquat pourrait endommager cet appareil. Utilisez des câbles de cuivre.

### ECM - CAF/Air Handler Wiring Diagram/ Schéma de câblage FAP/Appareil de traitement de l'air - moteur à commutation électronique ECM

- Black = noir
- White = blanc
- Red = rouge
- Blue = bleu
- Yellow = jaune
- Tan = havane
- Purple = pourpre
- Brown = brun



60-CAF-01-ECM  
0207

N. O.	Normally open Normalement ouvert
N. C.	Normally closed Normalement fermé
COM	Common
T#	Terminal
P#	Plug Prise
K#	Relay Relais
F#	Fuse Fusible
SW#	Switch Commutateur

## 18 LIFE BREATH LIMITED WARRANTY

AIRIA BRANDS INC.® (AIRIA) warrants to the original purchaser of the LIFE BREATH® model and accessories referred to below, to be free from manufacturing defects.

This Limited Warranty is personal to AIRIA® and is in effect from the installation date, but no later than 12 months after the date the product was manufactured (if the installation date cannot be verified, the warranty period will begin on the date of manufacture). The serial number can be used to determine the date of manufacture: XX XX MMDDYY ###; or MMDDYY ###. The warranty is dependent on the type of unit:

Type of Unit	Warranty
HRV Residential	Lifetime on the Core / 5 years on other components
HRV Commercial	15 years on the Core / 2 years on other components
ERV Residential	5 years on the Core / 5 years on other components
ERV Commercial	5 years on the Core / 2 years on other components
Accessories (e.g. controls and timers)	1 year
Replacement Parts (e.g. motor)	1 year
Clean Air Furnace (HRV)	Lifetime on the Core / 2 years on other components
Clean Air Furnace (ERV)	5 years on the Core / 2 years on other components
Air Handler	5 years
TFP	5 years

Damage resulting from all other causes, including but not limited to: lightning, hurricane, tornado, earthquake or any other acts of God; improper installation, modification, alteration or misuse of the LIFE BREATH® unit or its operation in a manner contrary to the instructions accompanying the unit at the time of sale; accidental or intentional damage, neglect, improper care, or other failure by the owner to provide reasonable and necessary maintenance of the product; any attempt at repair by an unauthorized service representative or not in accordance with this warranty; or any other causes beyond the control of AIRIA®, are excluded from this warranty.

If you feel that the LIFE BREATH® unit you purchased is not free from manufacturing defects, please refer to <https://www.lifebreath.com/homeowners-2/find-a-contractor/> to find the name of your nearest dealer in order to repair the product. The labour required to install any replacement part(s) is not covered by AIRIA®.

AIRIA® reserves the right to replace the entire unit or to refund the original purchase price in lieu of repair.

**AIRIA® MAKES NO EXPRESS WARRANTIES, EXCEPT FOR THOSE THAT SET FORTH HEREIN AND SHALL NOT BE LIABLE FOR ANY INCIDENTAL, SPECIAL OR CONSEQUENTIAL DAMAGES WITH RESPECT TO LIFE BREATH® COVERED BY THIS WARRANTY. AIRIA'S COMPLETE LIABILITY AND THE OWNER'S EXCLUSIVE REMEDY BEING LIMITED TO REPAIR OR REPLACEMENT ON THE TERMS STATED HEREIN. ANY IMPLIED WARRANTIES, INCLUDING BUT NOT LIMITED TO THE IMPLIED WARRANTY OF MERCHANTABILITY AND OF FITNESS FOR ANY PARTICULAR PURPOSE, ARE EXPRESSLY EXCLUDED.**

**NO PERSON IS AUTHORIZED TO CHANGE THE WARRANTY IN ANY WAY OR GRANT ANY OTHER WARRANTY UNLESS SUCH CHANGES ARE MADE IN WRITING AND SIGNED BY AN OFFICER OF AIRA®.**

MODEL NO.: \_\_\_\_\_

UNIT SERIAL NO.: \_\_\_\_\_

INSTALLED BY: \_\_\_\_\_

DATE: \_\_\_\_\_