

## **ENGINEERING DATA**

#### TOTAL RECOVERY CORE

The cross-flow energy recovery core transfers heat and water vapor between the two airstreams. It is easily removed for cleaning or service.

## **MOTORS AND BLOWERS**

Each airstream has an independent motorized impeller, with multiple fan speed operation.

#### FILTERS

Washable pre filters in exhaust and supply airstreams.

### **MOUNTING THE ERV**

Hanging straps supplied with the unit.

### FROST PREVENTION

Temperature sensor activated, supply bypass routes indoor air to defrost core. Drains not required.

### CASE

 $20\ \text{gauge}$  prepainted galvanized steel for superior corrosion resistance, insulated to prevent exterior condensation.

### **INSTALLER SELECTABLE HIGH SPEED SETTINGS**

The highest speed, "H3" is the factory setting. Installers may select a lower high speed on set up. See chart for airflows H1, H2, and H3.

# **ELECTRONICS**

The main control can be wall mounted in a central location. 3 wire 20 gauge (min.) 100 ft length (max.).

## **CONTROL OPTIONS**

### 99-DXPL02 Lifebreath Digital Control

- 5 speed operation on each mode
- Humidity control through adjustable Dehumidistat
- 5 user selectable operational modes: Continuous Ventilation, Continuous Recirculation, 20 ON/40 OFF. 10 ON/50 OFF. 20 ON/40 Recirculation
- 20/40/60 min. High speed override button
- Compatible with 99-DET02 Wireless Timers
- 3 wire connection

#### 99-BC04 Lifebreath Ventilation Control

- 2 speed fan setting (Low/High)
- 2 modes of operation: Ventilation, 20/40
- Compatible with 99-DET02 Wireless Timers
- 3 wire connection


## **TIMER OPTIONS**

- **99-DET01 Lifebreath 20/40/60 Minute Timer** Initiates High speed Ventilation for 20, 40 or 60 minutes. 3 wire connection.
- **99-DET02 WIRELESS Lifebreath 20/40/60 Minute Timer** Initiates High speed Ventilation for 20, 40 or 60 minutes. Wirelessly connects to main control for ease of installation. 40' approximate range.
- **99-RX02 WIRELESS Repeater** Used to extend range of 99-DET02 Wireless Timers. Plugs into 120V power outlet. Wirelessly connects to main control and 99-DET02. Install at halfway point between timer and main wall control if timer is out of range.

### **ACCESSORY OPTIONS**

99-163 Duct Heater w/Electronic SCR Thermostat - 1 kW, 6 in (152 mm) 99-186 Weatherhoods - Two 6 in (152 mm)

Performance Net supply airflow in cfm (L/s) against external static pressure			
External Static Pressure	Airflow		
@ 0.1 in (25 Pa)		cfm (99 L/s)	
@ 0.2 in (50 Pa)		cfm (92 L/s)	
@ 0.3 in (75 Pa)		cfm (87 L/s)	
@ 0.4 in (100 Pa)		cfm (80 L/s)	
@ 0.5 in (125 Pa)		cfm (73 L/s)	
@ 0.6 in (150 Pa) @ 0.7 in (175 Pa)		cfm (65 L/s)	
@ 0.8 in (200 Pa)		cfm (59 L/s)	
@ 0.9 in (225 Pa)		cfm (51 L/s)	
@ 1.0 in (250 Pa)		cfm (44 L/s)	
(230 T a)	/8	cfm (37 L/s)	
Max. Temperature R ecovery		87%	
S ensible E ffectiveness			
@ 64 cfm (30 L/s)	32°F (0°C)	87%	
Total Efficiency			
@ 64 cfm (30 L/s)	95°F (35°C)	53%	
VAC @ 60Hz		120	
Watts / Low speed		64	
Watts / High speed		96	
Amp rating		1.4	



**Total Efficiency:** Moisture and Thermal @95F **Effectiveness:** Based on temperature differential between the 2 airstreams






All units conform to CSA and UL standards

# **DIMENSIONS 230 ERVR**

WEIGHT 75 lbs (34 kg) SHIPPING WEIGHT 77 lbs (35 kg)



**NOTE:** All specifications are subject to change without notice.

Date:	Contractor:
Tag: Qty:	Supplier:
Project:	Quote #:
Engineer:	Submitted By

WARRANTY Units carry a 5 year warranty on the ERV core and a 5 year replacement parts warranty.